



Please call 231-399-0700

Email: justin@eco-buildingproducts.com

[Rubio Samples](#)

[Specs](#)

PRODUCT DATA SHEET

Sample Instructions

1. Shake the oil sample vigorously.
2. Pour a few drops of oil onto the wood sample and distribute it with a cloth, red buffer pad, or brush adding oil as needed.
3. After 5 to 10 minutes thoroughly remove all excess oil with a cloth or paper towel. You cannot remove too much oil.
4. Scrub the sample forcefully with a white polish pad.

Tips to improve the quality of your sample

Samples should be finished as closely as possible as your floor will be finished. Sand your sample with 100 grit paper and remove all dust before oiling. The results will more closely mirror the appearance of your finished floor. VOC free Monocoat oils have no ingredients in its composition to artificially speed up drying. Wait 24 hours after oiling your sample to judge the finished product. The color will be reasonably accurate shortly after oiling, but the appearance will not be accurate until the complete dry time has passed.

SPECIFIC FEATURES:

Rubio Monocoat Oil Plus colors and protects your wood in one layer. Unlike traditional hardwax oils, Rubio Monocoat Oil Plus will connect with wood fibers by means of a molecular reaction, as a result of which a durable protection is obtained. This molecular connection enables Rubio Monocoat Oil Plus to embed in the surface's upper microns immediately. The wood fibers can only combine with a certain amount of oil. Oil, which has not reacted, does not adhere and needs to be removed.

CONSUMPTION:

Pure Oil - 1 liter +/-500 sq. ft.
Color Oil - 1 liter +/- 350 sq. ft.
(1330 to 1900 sq. ft. per gallon)

WARNING:

Oil saturated cloths and paper towels can spontaneously combust and must therefore be burnt, placed in water or kept in a lid-sealed metal container.